

CA32C3BK
REFILL INSTRUCTIONS
For Canon® BC-32

Contents:

Your kit should contain the following:
4 - 2oz bottles of ink, 1 10cc syringe, 1 blunt needle, cotton
wipes, 1 drill tool, 4 screws, instructions.
If any of these items are missing please call us for a
replacement item or kit.



PLEASE WORK ON NEWSPAPER IN CASE OF SPILLAGE

BLACK & COLOR CARTRIDGE FILL SIMILARLY

- 1) Wrap black electrical tape around the cartridge, covering the ink port as shown in Figure 1. Black electrical tape is NOT provided in the kit unless you use the tape on the ink bottles.
- 2) Looking at the top of the cartridge locate the word PUSH on the top cartridge label. Using the drill tool provided in the kit, drill through the round indentation next to the word PUSH closest to the locking tap.. See Figure 2.
- 3) Attach the needle to the injector. Draw 10ml of ink into the injector. Inject all of the ink into the hole that you drilled in step #2. The black cartridge should hold another 10ml of ink so do this step again. (Do not repeat for color cartridges) See Figure #3 Inject the ink slowly.
- 4) Seal the hole that you drilled in step #2 with one of the silver screws provided in the kit. You will need to obtain a small Phillips screw driver. If you forget to seal the hole the cartridge will leak. If the cartridge still leaks seal the screw head with black electrical tape or a hot glue gun. It's important that the hole is sealed airtight or the cartridge **WILL** leak. **DO NOT INSERT A LEAKING CARTRIDGE INTO YOUR PRINTER.**
- 5) The color cartridge is very similar to the black for refilling instructions. Inject 10 – 15 cc of color ink into the correct cartridge and seal the hole as in step #4.



FIGURE 1



FIGURE 2



FIGURE 3