

CA40C3BK

REFILL INSTRUCTIONS

For Canon® BCI-21 Black & Color

Contents:

Your kit should contain the following: 4 2oz bottles of ink, 1 10cc ink injector, 2 poly wipes, 1 drill tool, needle, instructions.

If any of these items are missing please call us for a replacement item or kit.



Removing the cap.

The cap on the top of the cartridge must be removed. This can be accomplished very easily with a dull knife. Hold the cartridge with the label facing you. Insert the blade of the knife where the cap meets the cartridge and twist. The cap should pop off very easily. Be careful not to break the finger on the back of the cartridge. This finger holds the cartridge into the print head. Throw the plastic cap out, you do not need to put it back on the cartridge.

Instructions for black cartridge.

The 3 larger holes under the cap are not filling holes. The small hole in the center of the cartridge is the fill hole. In order to inject the ink you must first drill out the fill hole so the needle will fit. To enlarge the fill hole, drill until you feel the drill go through the other side. Now you are ready to inject the ink.

Draw 5cc of ink into the syringe. Insert the needle into the hole you just drilled as far as it will go. Slowly inject the ink while lifting upwards slightly as you go. Pause every once in a while so that the sponge becomes saturated. Watch the bottom of the cartridge for ink to drip from the sponge. Once ink starts to drip from the sponge draw back on the syringe plunger, this will stop the ink from dripping. You may use the cartridge immediately after you have finished refilling it. Rinse the needle and syringe off with warm water.

Instructions for color cartridge.

Once the cap is off you will see 6 holes. The 3 larger holes are not filling holes. The smaller holes are the fill holes. In order to inject the ink you must first drill out the fill holes. Using the drill tool supplied, drill until you feel the drill go through the plastic. Rinse the drill in water before drilling the next fill hole to avoid contamination. Now you can inject the ink.

Draw 3cc of the proper color ink into the syringe. Insert the needle into the vent hole as far as it will go. Slowly, inject the ink while lifting upwards slightly as you go to saturate the entire sponge. Watch the bottom of the cartridge for ink to drip from the sponge. Once ink starts to drip from the sponge draw back on the syringe plunger this will stop the ink from dripping. Rinse the needle between colors, if you are refilling more than one color. This will prevent contamination of the other colors. You may use immediately after you have finished refilling the colors.