

HP56BK
REFILL INSTRUCTIONS
For HP® C6656AN BLACK

Contents:
Your kit should contain the following:
2oz bottle of ink, 1 10cc ink injector, 1 poly wipe, needle,
rubber gloves, instructions.
If any of these items are missing please call us for a
replacement item or kit.



STEP 1

Set the cartridge to be filled on some newspaper in case of any ink spillage. Remove the label on the top of the cartridge. You will find 5 holes. You will be injecting the ink in the hole pictured above where it says "Fill Here".

STEP 2

Attach the needle to the injector/syringe and draw 10cc of ink. Dispense it **SLOWLY** into the cartridge until it has taken the full amount. Get the tip of the needle to the bottom of the cartridge. Do this again except only put 5cc of ink in the injector. The cartridge should hold about 15cc of ink.

STEP 3

It is not necessary to reseal the holes. Let the cartridge sit on a paper towel for about an hour to ensure there are no drips. It's actually best to let it sit over night.

TROUBLE SHOOTING

PRINTS IN STREAKS / MISSING LINES : Perform print head clean procedure as described in the owners manual.

CARTRIDGE LEAKS: Cartridge is overfilled. Use the injector to remove some of the ink.

ATLASCOPY.COM
P.O. Box 1292
Dover, DE 19904
<http://atlascopy.com>