

KCE10C5B **REFILL INSTRUCTIONS** **For Epson® T07201, T08201,** **T09201**

Contents:

Your kit should contain the following:

KCE10 ChipResetter

6 - 2oz bottle of ink, 1 10cc ink injector, 2 polly wipes, 12 yellow seals, needle, drill tool, instructions.

If any of these items are missing please call us for a replacement item or kit.

1. Cover exit port hole with adhesive tape (must be dry). Exit ports are on the bottom of the cartridge.

2. Locate the refill holes on top of cartridge. Use the drill tool, if necessary, to enlarge the hole. There are two holes to each color chamber, drill one of the holes.

3. Draw 3 - 5 ml(cc) ink into syringe from ink bottle and inject ink very slowly for each color. Repeat for all five colors. Draw 10 cc for the black cartridge.

4. Remove tape from exit ports, use the round yellow seals to cover the exit ports after you have removed tape. Make sure the port is dry before attaching the seal. Do not seal the fill holes on the top of the cartridge, these act as a vent for the cartridge.

5. Reinstall cartridge and do the cleaning cycle at least 2 - 3 times.

Remember the Smart chip must be reset for this refill kit to work.

