

REFILLING THE CANON® BX-3 CARTRIDGES

Place the cartridge on your work surface with the clear plastic side up. Find the steel ball which seals the refill hole of the cartridge. Using a ball point pen, push the steel ball into the cartridge. Don't worry, it won't hurt anything to have the ball inside of the cartridge. Fill the cartridge using the steps mentioned earlier. If the cartridge overflows, draw out a small amount of ink. Use the wipe to clean around the hole and seal with ordinary transparent tape.

Troubleshooting

- 1) Leaking - The cartridge is overfilled. Let it stand, vent down on a paper towel until it stops.**
- 2) Streaks - Perform the print head cleaning routine again. If problem still exists, remove the cartridge and try soaking the print head in hot water for about 5 minutes.**
- 3) Won't print - blank - Perform the print head cleaning routine.**
- 4) Smears - Cartridge may be leaking. Remove from the printer and let it sit on a paper towel until the leaking stops.**

**ATLASCOPY.COM
P.O. BOX 1292
DOVER, DE 19904
HTTP://ATLASCOPY.COM**